
SCULCONPARCED BY THE METAL AND THE PARCED BY THE PARCED

Sculcon Junction Box with Ground Plug & Cable

DESCRIPTION

The control monitor connects to a heavy duty Sculcon® junction box with attached cable and special quick release snap-on plug. The Scully Ground Plug connects to a specially designed electronic Scully Ground Ball mounted on each vehicle. The controller in conjunction with the ground ball provides and verifies vehicle grounding before loading can begin. The controller must receive an electronic return signal from the ground ball throughout the loading operation.



ORDERING INFORMATION

Description	Part Number
SC-47 Sculcon Junction Box, Ground Plug, Blk Straight Cable, 20'	08249
Replacement Plug and 20' Straight Cable Assembly for SC-47 Sculcon Junction Box	08219
SC-47 Sculcon Junction Box, Ground Plug, Blk Coil Cable, 32'	08567
Replacement Plug and 32' Coiled Cable Assembly for SC-47 Sculcon Junction Box	08566
Replacement Plug only	08565
SC-47 Sculcon Box Assy, General Purpose	32319
Strain Relief, 3/8" for Grounding Cable	32445



